

## Termination Boxes

### Optional Termination Box Accessories

#### Splice Protector

FibreFab splice protectors are used to protect the fibre splice. They are 2.4mm in diameter, and 45mm and 60mm in length. Only needed for applications where more than 4 splices are required.



#### Splice Protector

Description	Product Code
45mm Splice Protector	SPLICE45CLEAR
60mm Splice Protector	SPLICE60CLEAR

#### Security Screw Kit

Provides secure, restricted access to prevent unauthorised entry. A special tool is required to gain access to the box.



**NEW**

#### Security Screw Kit

Description	Product Code
Security Screw Kit	SECURESCREW

#### Sealant Kit

A kit containing a unique polyurethane sealant used for sealing the cable interstices within the unit. The sealant is dispensed from a hermetically sealed 170ml co-axial cartridge system, once mixed through the mixing nozzle and applied the sealant is an inert material.



#### Sealant Kit

Description	Product Code
Sealant Kit	SEAL01

#### Gas Seal Conn

Used for sealing a Blown Fibre tube. The connector simply fits over the tube providing a gas tight seal.



**NEW**

#### Gas Seal Conn

Description	Product Code
Gas Seal Conn	GASSEALCON

#### Customer Lead In Unit (CLI)

Used to guide the input fibre cable through the wall into the Internal/external Termination Box



**NEW**

#### Customer Lead In Unit

Description	Product Code
Customer Lead In Unit	FIBRELEADIN